

ISTRUZIONI MONTAGGIO SILVERHOOK-BR

LEGENDA IMMAGINE 1

A - GANCI ASSEMBLATI PER MONTAGGIO SU BLURAY (2)

B - VITE DI FISSAGGIO (2)



INSERIMENTO E POSIZIONAMENTO DEI GANCI SULLA SILVERMOON (IMMAGINE 2)

Inserire i ganci in acrilico sulle cave laterali della barra e posizionarli con l'interasse desiderato.


AGGANCIAMENTO DELLA SILVERMOON ALLA PLAFONIERA BLURAY (IMMAGINE 3)

La SILVERMOON è ora pronta per essere agganciata alla plafoniera BLURAY mediante inserimento dall'alto dei ganci in acrilico sulla prima aletta del dissipatore.

E' possibile regolare l'angolazione della barra in base alle proprie preferenze. Fissare la posizione mediante serraggio della vite B con chiave a brugola da 2,5 (IMMAGINE 4).



Nel caso di montaggio di una sola Silvermoon, occorre intervenire sul cavetto di sospensione della Bluray per equilibrare lo sbilanciamento di peso. Allentare il grano del cilindretto di regolazione, posizionare il cavetto in modo che la plafoniera torni in assetto orizzontale, poi serrare di nuovo il grano che blocca il cavetto sul cilindretto di regolazione.



SILVERHOOK-BR MOUNTING INSTRUCTIONS

IMAGE 1 - CAPTION

A - HOOKS ASSEMBLED FOR MOUNTING ON BLURAY (2)

B - FIXING SCREW (2)

INSERTING AND POSITIONING THE HOOKS ON THE SILVERMOON (IMAGE 2)





Insert the hooks into the side recesses of the bar and position them with the desired wheelbase.

ATTACHMENT OF THE SILVERMOON TO THE BLURAY CEILING LIGHT (IMAGE 3)

The SILVERMOON is now ready to be hooked to the BLURAY by inserting the acrylic hooks on the top, on the first fin of the heatsink.

You can adjust the bar angle according to your preferences.

Fixing the position by tightening screw B with 2.5 Allen key (IMAGE 4).



In case of installation of only one unit Silvermoon, you need to take action on Bluray suspension cable, to balance the weight. Loosen the grain of the cylinder of adjustment, position the cable in such a way that the ceiling light turns back in horizontal trim, then tighten again the grain that blocks the wire on the adjusting cylinder.